




# TOP AND CONSOLE PARTS

For Model: EGD4100SQ0

(Designer White)

29" GAS DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP AND CONSOLE PARTS

For Model: EGD4100SQ0

(Designer White)


<b>Illus.</b>	<b>Part</b>		<b>Illus.</b>	<b>Part</b>		<b>Illus.</b>	<b>Part</b>	
<b>No.</b>	<b>No.</b>	<b>DESCRIPTION</b>	<b>No.</b>	<b>No.</b>	<b>DESCRIPTION</b>	<b>No.</b>	<b>No.</b>	<b>DESCRIPTION</b>
1		Literature Parts	6	3395683	Connector (Motor)	21	8299763	Timer
	8578193	Guide, Use & Care	7	8274434	Cap, End (R.H.)	22	3391249	Tie, Cable
	8562589	Instructions, Installation	8	357213	Nut, Push-In (2)	23	8299875	Harness, Wiring
	W10043000	Sheet, Cycle Feature	9	8274261	Panel, Rear Console	24	3403499	Connector, 2-Position (Gas Valve)
	8528187	Wiring Diagram	10	8558467	Screen, Lint	25	3403498	Connector, 3-Position (Gas Valve)
<b>Following May Be Purchased</b>			11	8536939	Clip, Spring	26	8533971	Screw, 8-18 x 5/16
<b>DO-IT-YOURSELF REPAIR MANUALS</b>			12	694419	Buzzer, Mini	30	3977456	Switch, Push-To-Start
			13	688983	Screw, 8-18 x 5/8	31	8538953	Timer Knob Assembly
			14	388326	Screw, Console	32	8271418	Bracket, Control
			15	3394427	Clip, Harness	33	8573821	Panel, Control
			16	8557930	Top	34	717252	Receptacle
			17		Wire, Jumper	35	8538959	Knob, Push-To-Start
			18	3393815	Light-Blue			
			19	94614	Terminal			
			20	8533951	Screw, Grounding			
				688805	Clip			
2	693995	Screw, Hex Washer Head						
3	3397269	Connector, Timer						
4	8274437	Cap, End (L.H.)						
5	3936144	Connector						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

For Model: EGD4100SQ0

(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

## For Model: EGD4100SQ0

(Designer White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	697776	Screw, 10-32 x 5/8	20	690363	Lock, Front Top (2)	34	691366	Idler & Pulley Assembly
2	343641	Screw, 10-16 x 1/2	21	3394895	Front Panel Assembly	35	8066065	Belt, Drive
3	693995	Screw, Hex Head	23	685203	Clip, Felt Pad	36	348780	Base, Motor
4	8541400	Bracket, Cabinet	24	3389441	Catch, Door	37	3400500	Bolt, 5/16-18 x 3/4
5	3396795	Cover, Block	25	348023	Hinge & Pin Assembly (2)	38	8066184	Pulley, 60 Hz.
6	3394975	Plug, Front Panel	26	696144	Strike, Door	39	8066206	Motor, 60 Hz.
7	3396807	Panel, Rear	27	695656	Door, Rear	40	660658	Clamp, Motor
8	342055	Screw, 8-18 x 1/2	28	348205	Door, Front	41	3404162	Clamp, Motor (W/Shield)
9	3980175	Clamp, Elbow	29	686711	Handle, Door	42	8318272	Burner Assembly, 60 Hz.
10	3406102	Door Switch Assembly	30	8066123	Seal & Bearing Assembly			(Refer To Pages 5 & 6 For Further Breakdown)
11	697773	Screw, 6-20 x 7/8	31	3390734	Seal, Door	43	341029	Clamp, Pipe
14	694091	Screw, 8-18 x 3/8	32	344020	Cord, Power			
15	3394083	Clip, Front Panel	33	8066217	Hinge, Top (2)			
16	3392100	Foot, Dryer (4)						
18	8530603	Cabinet (Includes Illus. 4)						
19	98234	Clip, Ground (2)						


# 8318272 BURNER ASSEMBLY

For Model: EGD4100SQ0

(Designer White)

USE WITH TYPE 1 – NATURAL

AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# **8318272 BURNER ASSEMBLY**

**For Model: EGD4100SQ0**

**(Designer White)**

**USE WITH TYPE 1 – NATURAL  
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES**

Illus.	Part No.	DESCRIPTION
	No.	
1	8318272	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8-32 x 5/8)
6	343641	Screw, 10-16 x 1/2
7	693986	Base, Burner
8	3387057	Screw, 8-18 x 3/8
9		Orifice, Burner
	234826	Type 1
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	8318277	Valve, 60 Hz. (Includes Pipe & Illus. #7)
11	694421	Screw, 8-32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
25	341029	Clamp, Pipe

---

## **Following Parts Not Illustrated**

---

**694572 Conversion Kit  
(Type 1)  
to Type (4) L.P.G.**


**BA-150**

**FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST**

# BULKHEAD PARTS

**For Model: EGD4100SQ0**

(Designer White)



<b>Illus.</b>	<b>Part</b>	
<b>No.</b>	<b>No.</b>	<b>DESCRIPTION</b>
1	694283	Lint Chute Assembly
2	343641	Screw, 10-16 x 1/2
3	3406022	Bracket, Bulkhead
4	3388703	Washer, Support
5	90767	Screw, 8-18 x 3/8
6	3392519	Fuse, Thermal
7	347139	Seal, Lint Chute
8	660039	Thermostat, Internal Bias
9	8066086	Drum Hole Plug
10	694089	Wheel, Blower (Includes Illus. 27)
11	8577230	Housing, Blower

<b>Illus.</b>	<b>Part</b>	
<b>No.</b>	<b>No.</b>	<b>DESCRIPTION</b>
12	3398161	Clip
13	489463	Screw, 8-18 x 5/8
14	8530285	Box, Heater
15	3403140	Thermostat, 205°F (96C)
16	280010	Kit, Thermal Cut-Off (Includes Illus. 15)
17	3401707	Wire, Jumper
18	8066048	Funnel, Burner
19	3390647	Screw, 8-18 x 1/2
24	696302	Shield, Exhaust
26	3392247	Pad, Blower Housing

<b>Illus.</b>	<b>Part</b>	
<b>No.</b>	<b>No.</b>	<b>DESCRIPTION</b>
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397590	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8-16
48	8529955	Bulkhead
49	338906	Sensor, Radiant
62	3394508	Ring, Bearing
63	97787	Screw, 11-16 x 3/4
66	8066085	Seal, Rear Drum
67	695584	Drum Assembly
68	342847	Baffle, Drum
69	3976435	Bracket, Support
70	90296	Clip
73	339956	Seal

**FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST**

# **OPTIONAL PARTS (NOT INCLUDED)**

For Model: EGD4100SQ0

(Designer White)

<b>Illus.</b>	<b>Part</b>	
<b>No.</b>	<b>No.</b>	<b>DESCRIPTION</b>

## **ACCESSORY PARTS**

279948	Kit, Dryer Repair
8522199	Kit, Dryer Vent Testing
346764	Kit, Hold-Down (Gas Dryer Mobile Home Installation)
689790	Dry Rack

## **PAINT, TOUCH-UP (1/2oz.)**

72017 White

## **PAINT, PRESSURIZED SPRAY**

**(12 oz.)**

350930	White
350938	Primer, Gray

## **PAINT, BULK (1 qt.)**

799344 White (Uncut)